











Belangrijk! Lees deze instructie voor gebruik!
Important! Read these instructions before use!
Achtung! Lesen Sie diese Anweisungen für den Einsatz!
Important! Lisez ces instructions pour l'utilisation!

Vrijstaande oven/magnetron
 Stand four/micro-ondes
 Selbststehendes Ofen/Mikrowellengerät
 Self-standing oven/microwave oven



	A	B1	B2	C	D	E	F	G	H
MO516___ / MO716___	560	590	600	550	566	546	596	595	20
CM514___ / CM714___	560	450	460	550	565	545	454	595	20



983276